

## INSTRUCTIONS FOR PERFORATING AIR FLOTATION TABLE TOPS USING A TEMPLATE

- 1. Place the template on the upper surface of the table top, and clamp it to the table top.
- 2. Using a hand held electric drill and the 1/8" drill bit provided, drill a hole through the table top at the locations in the template.
- 3. Using the razor blade provided, clean any rough edges around the holes at the bottom of the table top.